

Fornace Polirone

di Cappelli e Pasqualini S.n.c.

Via Argine Boccadiganda, 1
46030 BORGOFORTE (Mantova)
Tel. 0376/648612 - Fax 0376/648677
Email: fornacepolirone@tin.it
www.polirone.com

DIRECTIONS FOR THE LAYER AND TREATMENT OF OUR FLOOR

Our floor can be layered either with glue or with subfloor.

Tiles must be taken from all the packages, thus to avoid the variations in the finished floor. In general, this is to keep the leakage as little as possible, in relation to the irregularity of the tiles. In the event of alignment layer (gaps of about 2 mm), it is necessary the use of calibrated tiles.

With the flooring, we supply the inert for the plastering and sealing of the joints. To prepare the cement grout mix together inert and white cement in equal part, in a way that it can infiltrate well between the gaps.

Before the floor is laid, it is necessary to wet it few times until there is a refuse of the water. Verify that the grout mix does not become dry otherwise with time the plastering of the holes can come off. Do not use waterproof products before plastering because it does not help the grip of the grout mix or "boiaccia" (water-dust of brick-white cement).

The most important operation is cleaning, in fact the surface of the floor must be perfectly clean (with a cloth or sponge) and it must not show any trace of grout mix. It is very important to clean following the sense of the gaps, in a way that between the two tiles, not perfectly even, the grout mix can be removed.

At the end of the operation of layering and plastering, it is necessary to wait for the floor to dry

(maximum humidity 10%) and then proceed with the treatment.

At this stage the floor needs to "breathe" and therefore it cannot be covered with nylon or cardboard to avoid the build up of oxidation. For further works that can spoil the floor with varnish, oil o other liquids, protect the floor with the time strictly needed, and then remove the protection.

Before to start applying the wax, pay attention that there are no evident oxidations on the floor and, if any, it is necessary to remove them.

The Company Fornace Polirone advice to treat their floors with natural waxing and sealing, and to avoid silicone substances or varnish. For the ordinary and extraordinary maintenance of the floor, it is necessary pay attention to the instructions of the Company producer of the treatment.

The outdoor floors cannot be treated with waterproof products.

For more information, please do not hesitate to contact directly Fornace Polirone.

FORNACE POLIRONE S.n.c.